



For houses with open soffits, **Eave Vents** fit snugly between **Rafters**, replacing the wooden 2 x 6 (or 2 x 4) **Frieze Block**. If the vent doesn't take up the whole space or a rough opening hole can be cut in the Frieze Block. Nail through the side flanges to secure the vent to the rafters.

Caution: Eave Vents have *very sharp edges!* Use gloves to prevent injury.

| Size | CMI Part # | N.F.V. | Rough Opening | Gross Size |
|--------------------|------------|-------------|-----------------------|----------------------|
| 14 in. x 5 in. | EV145 | 44 sq. in. | 14.25 in. x 5.75 in. | 14.5 in. x 5.5 in. |
| 14 in. x 6 in. | EV614 | 44 sq. in. | 14.25 in. x 5.75 in. | 14.5 in. x 5.5 in. |
| 22 in. x 3 in. | EV223 | 39 sq. in. | 22.375 in. x 3.75 in. | 22.125 in. x 3.5 in. |
| 22 in. x 6 in. | EV622 | 71 sq. in. | 22.25 in. x 5.75 in. | 22 in. x 5.5 in. |
| 22 in. x 7 in. | EV722 | 102 sq. in. | 22.25 in. x 7.75 in. | 22 in. x 7.5 in. |
| 22 in. x 3.5 in. | EVL223-PX | 40 sq. in. | 22.75 in. x 3.75 in. | 22.5 in. x 3.5 in. |
| 22.5 in. x 3.5 in. | EV223-PX | 40 sq. in. | 22.75 in. x 3.75 in. | 22.5 in. x 3.5 in. |
| 22.5 in. x 3.5 in. | EV223-LV | 40 sq. in. | 22.75 in. x 3.75 in. | 22.5 in. x 3.5 in. |